



Instructions For Use

Screw male component into reverse of the article (sign or letter) to be mounted, to provide rear-wardly projecting threaded boss. The bosses (male part) are pointed so that they may be used to mark accurately the positions on the walls at which the sockets (female part) are to be fixed.

The sockets (female part) are then screwed to the wall or support so as to be rotatable on the screws and are then screwed around the mounted bosses (male part) until tight.

For wooden letters and fitments with wooden backing Type "B" is applicable, having an 8 gauge woodscrew stud.